


Defocus Techniques for Camera Dynamic Range Expansion

Matthew Trentacoste, Cheryl Lau, Mushfiqur Rouf,
Rafal Mantiuk, Wolfgang Heidrich



University of British Columbia

Defocus DR expansion

- Sensors limited in dynamic range
Can be expanded, but tradeoffs exist
- Evaluate the opposite, reduce the dynamic range of the scene incident on the sensor by optical blurring, restore in software




Approach




- Use 2 techniques to aid:
coded aperture + deconvolution
- Aperture filter to improve deconvolution quality
PSF preserves more information
[Rashkar 2006][Levin 2007][Veeraraghavan 2007]
- Deconvolution to restore original image
Recent advances using natural image statistics
[Bando 2007][Levin 2007]

Physical setup




- Rays from scene pass through aperture plane and focused onto sensor
- Cone of rays from out-of-focus points intersects sensor, forming the shape of the aperture
- A pattern in the aperture plane is projected onto the sensor for out-of-focus points

Coded Aperture




- Originally from x-ray astronomy
[Fenimore 1978][Gottesman 1989]
- Structured arrays + decoding algorithm with resolution of pinhole, but better SNR
- Employed in visible light photography
[Rashkar 2006][Levin 2007][Veeraraghavan 2007]
- Improve frequency properties of filter

Aperture filters



- What makes a good filter?
 - Frequency response
 - Position and spacing of zero frequencies
 - Diffraction / transmission




Deconvolution


- Restore image distorted by PSF
[Wiener 1964][Richardson 1972][Lucy 1974]

$$f = f_0 \otimes k + \eta$$

- Ill-posed, infinite solutions
- No exact solution due to noise
- Division in FFT, issues with small values in OTF of filter



Deconvolution



- Current state-of-the-art methods rely on natural image statistics
- Real-world images share several properties:
Heavy-tail distribution of gradients
- Prior term in deconvolution algorithms
[Bando 2007][Levin 2007]
- Favors interpretations of the image with all the gradient intensity at a few pixels

Evaluation

- Goal : determine whether any combo of filter / deconvolution yields meaningful reduction in DR with acceptable final image quality
- Measure DR reduction both in terms of image local contrast and filter
- Measure image quality as difference between deconvolved and original images

Source material



Atrium Morning

Radius	Atrium Morning			Atrium Night		
	min	max	reduction	min	max	reduction
Original	0.00	11.0		0.00	12.0	
1	0.00	10.8	0.200	0.452	12.0	0.452
2	0.00	10.6	0.424	0.622	12.0	0.622
3	0.00	10.3	0.716	1.163	11.8	1.34
4	0.02	10.0	1.00	1.436	11.4	1.99
5	0.08	9.94	1.14	1.589	11.4	2.23
6	0.15	9.92	1.24	1.731	11.2	2.51
8	0.31	9.83	1.48	1.890	10.8	3.13
9	0.40	9.79	1.61	1.950	10.5	3.41
11	0.66	9.71	1.94	2.08	10.3	3.74
13	0.86	9.67	2.19	2.18	10.1	4.13
16	1.04	9.59	2.45	2.26	9.61	4.65



Atrium Night

Source material



Atrium Morning

Radius	Atrium Morning			Atrium Night		
	min	max	reduction	min	max	reduction
Original	0.00	11.0		0.00	12.0	
1	0.00	10.8	0.200	0.452	12.0	0.452
2	0.00	10.6	0.424	0.622	12.0	0.622
3	0.00	10.3	0.716	1.163	11.8	1.34
4	0.02	10.0	1.00	1.436	11.4	1.99
5	0.08	9.94	1.14	1.589	11.4	2.23
6	0.15	9.92	1.24	1.731	11.2	2.51
8	0.31	9.83	1.48	1.890	10.8	3.13
9	0.40	9.79	1.61	1.950	10.5	3.41
11	0.66	9.71	1.94	2.08	10.3	3.74
13	0.86	9.67	2.19	2.18	10.1	4.13
16	1.04	9.59	2.45	2.26	9.61	4.65

2.45 EV



Atrium Night

Source material



Atrium Morning

Radius	Atrium Morning			Atrium Night		
	min	max	reduction	min	max	reduction
Original	0.00	11.0		0.00	12.0	
1	0.00	10.8	0.200	0.452	12.0	0.452
2	0.00	10.6	0.424	0.622	12.0	0.622
3	0.00	10.3	0.716	1.163	11.8	1.34
4	0.02	10.0	1.00	1.436	11.4	1.99
5	0.08	9.94	1.14	1.589	11.4	2.23
6	0.15	9.92	1.24	1.731	11.2	2.51
8	0.31	9.83	1.48	1.890	10.8	3.13
9	0.40	9.79	1.61	1.950	10.5	3.41
11	0.66	9.71	1.94	2.08	10.3	3.74
13	0.86	9.67	2.19	2.18	10.1	4.13
16	1.04	9.59	2.45	2.26	9.61	4.65

2.45 EV 4.56 EV



Atrium Night


Tests

- Filters evaluated:
 - Normal aperture
 - Gaussian
 - Veeraraghavan
 - Levin
 - Zhou


- Deconvolution evaluated:
 - Wiener filtering
 - Richardson-Lucy
 - Bando
 - Levin




Circular



Gaussian



Veeraraghavan



Levin



Zhou

Evaluation (cont)

- Success criteria:
- Reduction of at least 2 stops to justify the computational cost of deconv
- Quality of at least PSNR 35

Images



Weiner



Richardson-Lucy




Bando




Levin

filter=Zhou, noise = 0, radius = 1


Images



Weiner



Richardson-Lucy




Bando




Levin

filter=Zhou, noise = 0, radius = 5


Images



Weiner



Richardson-Lucy



Bando




Levin


filter=Zhou, noise = 0, radius = 16

Deconv: no noise

Atrium Morning deconvolution




Atrium Night deconvolution




Aperture: no noise

Atrium Morning aperture filter




Atrium Night aperture filter




Deconv: noise

Atrium Morning deconvolution




Atrium Night deconvolution




Aperture: noise

Atrium Morning aperture filter



Atrium Night aperture filter



Conclusions

- Levin deconv the best, obtaining results with coded filters at *very* low noise levels
- No combination of filter and deconvolution consistently produced acceptable results
- Efficiency of the approach is scene dependent
Most efficient for small, isolated bright regions